



- (D)** Montage- und Bedienanleitung
- (GB)** Installation and operating instructions
- (NL)** Montagehandleiding en Gebruiksaanwijzing
- (F)** Instructions de montage et mode d'emploi
- (E)** Instrucciones de la instalación y de funcionamiento
- (I)** Istruzioni di montaggio e per l'uso
- (RUS)** Установка и инструкции по эксплуатации




51115 01 0000

3-Loch Waschtischarmatur mit Zugstange



1




2




3




4




5




6









7




8



9



i



i

